

Run Winding

Start Winding

| | NuStart |
|-----|---------------|
| 1 | RUN WINDING |
| N/C | NOT USED |
| 2 | NEUTRAL |
| 3 | START WINDING |
| N/C | NOT USED |
| 4 | COMMON |