

# NuStart

1 RUN

N/C RUN CAP

2 ACTIVE


3 START WINDING

N/C NOT USED

4 COMMON

## COLOR CODE

BK ----- BLACK  
BL ----- BLUE  
BL/PK ----- BLUE/PINK STRIPE  
BR ----- BROWN  
OR ----- ORANGE  
PU ----- PURPLE  
RD ----- RED  
WH ----- WHITE  
YL ----- YELLOW  
YL/PK ----- YELLOW/PINK STRIPE



Ensure the cable is placed through the current clamp.