




#### NuStart

- |     |               |
|-----|---------------|
| 1   | RUN           |
| 2   | RUN CAP       |
| 3   | ACTIVE        |
| 4   | START WINDING |
| N/C | NOT USED      |
| 5   | COMMON        |