

NuStart

1 RUN WINDING

N/C RUN CAP

2 ACTIVE

3 START WINDING

N/C ON/OFF

4 COMMON