



Remove red wire connection at L1 and tie it to the SureStart's [1]

Connect [2] to L1.

Connect [3] and [4] as shown.

NuStart	
1	RUN
N/C	RUN CAP
2	ACTIVE
3	START WINDING
N/C	NOT USED
4	COMMON