


TWZ048A100A1

WIRING D



NuStart 1 - HI		NuStart 2 - LO	
1	RUN	5	RUN
N/C	RUN CAP	N/C	RUN CAP
2	ACTIVE	6	ACTIVE
3	START WINDING	7	START WINDING
N/C	NOT USED	N/C	NOT USED
4	COMMON	8	COMMON